

# D16

SECTIONAL VALVE



 **walvoil**  
MOTION BY PEOPLE

TECHNICAL CATALOGUE

A member of



 **walvoil**  
MOTION BY PEOPLE

**3<sup>rd</sup> edition Jan.2024**

---

**Additional information**

*This catalogue shows the product in the most standard configurations.  
Please contact Sales Dpt. for more detailed information or special request.*

**WARNING!**

*All specifications of this catalogue refer to the standard product at this date.  
Walvoil, oriented to a continuous improvement, reserves the right to  
discontinue, modify or revise the specifications, without notice.*

*WALVOIL IS NOT RESPONSIBLE FOR ANY DAMAGE CAUSED BY AN  
INCORRECT USE OF THE PRODUCT.*



### Applications

The valve is available with manual, hydraulic remote, pneumatic, electrohydraulic and electropneumatic controls. Numerous configurations and solutions are possible. Working sections have auxiliary valves and a broad range of interchangeable spools. Special versions for LS variable pumps can be realised on request. Suitable for applications including Backhoe loaders, Wheel loaders, Backhoes, Compactor, Hook and Skip loaders, Drilling machines.

D16 has available:

Special inlet section with second pump managing system (Backhoe loaders).

Electric operated clamping valve (Backhoe loaders).

Special inlet with priority function for steering.

Special intermediate section for combination with D20 and D25.





## QUICK REFERENCE GUIDE

GENERAL SPECIFICATION	D9	D3M	DVS10	D4	D6	D16	D12	DVS20	D20	D25	D40
Working sections number	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-10
<b>CIRCUIT</b>											
Parallel	●	●	●	●	●	●	●	●	●	●	●
Series	●	●	●	●	●	●	●	●	●	●	●
Tandem	●	●	●	●	●	●	●	●	●	●	●
Parallel circuit stroke (mm)	6	5	6	6	7	7	9,5	9,5	9,5	12	15
Series circuit stroke (mm)	6	5	6	6	5	7	6,5		6,5	8,5	
Float spool extra stroke (mm)	5	5	5	5,5	6	7	7	7	7	9,5	10
Spools pitch (mm)	31	38	35	40	46	46	56	56	64	75	91
<b>RATED FLOW</b>											
Max recommended flow rate (l/min)	35	55	45	80	100	150	180	250	250	380	700
Max recommended flow rate (GPM)	10	15	12	22	27	40	48	67	67	100	185
<b>RATED PRESSURE</b>											
Max working pressure (bar)*	315	350	350	350	315	350	350	250	350	350	350
Max working pressure (PSI)*	4500	5000	5000	5000	4500	5000	5000	4000	5000	5000	5000
NOTE (*): Intermittent pressure at max. 1 million cycles with specific internal testing.											
OPTION CHART	D9	D3M	DVS10	D4	D6	D16	D12	DVS20	D20	D25	D40
Direct acting pressure relief valve	●	●	●	●							
Pilot operated pressure relief valve	●		●	●	●	●	●	●	●	●	●
2 stage pilot operated relief valve	●		●	●	●	●	●		●	●	●
Externally piloted valve	●	●	●	●	●	●	●		●	●	●
Solenoid dump valve (12 Vdc)	●	●	●	●	●	●	●				
Solenoid dump valve (24 Vdc)	●	●	●	●	●	●	●				
Main anticavitation check valve	●		●	●	●	●	●	●	●	●	●
Clamping valve	●		●								
<b>SPOOL ACTUATION</b>											
Manual control	●	●	●	●	●	●	●	●	●	●	●
Without lever	●	●	●	●	●	●	●	●	●	●	●
90° joystick control	●		●	●	●	●					
Hydraulic control	●	●	●	●	●	●	●	●	●	●	●
Direct electric control (12-24 Vdc)	●		●								
<b>SPOOL RETURN ACTION</b>											
Spring return	●	●	●	●	●	●	●	●	●	●	●
Detent in A - in B - in A/B	●	●	●	●	●	●	●	●	●	●	●
Detent in 4 <sup>th</sup> position	●	●	●	●	●	●	●	●	●	●	●
Arrangement for dual control	●	●		●	●	●	●				
Hydraulic load limit	●	●		●	●	●					
Pneumatic control ON - OFF	●	●	●	●	●	●	●	●	●	●	●
Proportional pneumatic control	●	●	●	●	●	●	●	●	●	●	●
Electrical load limit	●	●		●	●	●					
Electrohydraulic control ON-OFF (12-24 Vdc)	●	●	●	●	●	●	●	●	●	●	●
Electrohydraulic control PROP. (12-24 Vdc)	●	●	●	●	●	●	●	●	●	●	●
Electropneumatic control (12-24 Vdc)	●	●	●	●	●	●	●				
<b>AUXILIARY VALVES</b>											
Antishock valve	●	●	●	●	●	●	●	●	●	●	●
Anticavitation valve	●	●	●	●	●	●	●	●	●	●	●
Combined valve	●	●	●		●	●	●		●	●	●
Pilot combined valve						●		●	●	●	●



## GENERAL INDEX

4	<b>General specifications</b> Standard working conditions Fluid options
5	<b>Order example</b> Standard thread Thread codes Tie-rod kit classification Painting
7	<b>Dimensions</b>
8	<b>Typical curves</b> Pressure drop (P - T) Pressure drop (P - A/B) Pressure drop (A/B - T) Direct relief valve curve Combined valve curve Antishock valve curve Anticavitation check valve curve
10	<b>Inlet Section</b> Order example Inlet side classification Valve identification Valve arrangement Inlet position and available thread type
13	<b>Working section</b> Order example Spool identification Spool actuation classification for manual control Spool actuation classification for hydraulic control Spool return action classification - Spring load values Work section identification Auxiliary valves identification
27	<b>Intermediate inlet section</b> Order example Intermediate inlet section classification Valve identification on intermediate inlet section Valve arrangement on intermediate inlet section Inlet position and available thread type
30	<b>Intermediate outlet section</b> Order example Intermediate outlet section classification Inlet position and available thread type (for BF intermediate) Inlet position and available thread type (for BG intermediate)
33	<b>Outlet section (version 1 outlet)</b> Order example
33	<b>Outlet section (HPCO version outlet)</b> Order example - HPCO version outlet Outlet with single tank classification Outlet with two tanks classification Carry-over connection (HPCO)
37	<b>D16 Spare parts list</b> Gasket kits
41	<b>Installation and maintenance</b>
43	<b>General conditions and patents</b>



## GENERAL SPECIFICATIONS

## Standard working conditions

Description	Value
Ambient operating temperature range	-40°C / +60°C
Kinematic viscosity range	10 ÷ 300 cSt
Max contamination level	9 (NAS 1638) - 20/18/15 (ISO 4406:1999)
Recommended filtration level	b10 > 75 (ISO 16889:2008)
Internal filter (on electroproportional valves pilot line)	30 µm

All information and diagrams in this catalogue refer to a mineral base oil VG46 at 50°C temperature (32 cSt kinematic viscosity)

## Fluid options

Types of fluid (according to ISO 6743/4) Oil and Solutions	Temperature (°C)		Compatible gasket
	min	max	
Mineral Oil HL, HM (or HLP acc. to DIN 51524)	-25	+80	NBR
Oil in water emulsions HFA	+5	+55	NBR
Water in oil emulsions HFB	+5	+55	NBR
Polyglycol-based aqueous solution HFC	-10	+60	NBR

For special applications and different fluids, please call our Technical Department.



**ORDER EXAMPLE**

**D16/1: IR 009 150 A G05 | W001A H001 F001A RP G05 01 PA 100 05 PB | TJ A G06**

**TYPE:** \_\_\_\_\_

**D16:** product type

**/1:** working section number

**1) INLET ARRANGEMENT: pag. 10** \_\_\_\_\_

**IR 009** inlet side and valve type

**150** setting (bar)

**A G05** inlet position and available thread type

**2) WORK SECTION ARRANGEMENT: pag. 13** \_\_\_\_\_

**W001A** spool type

**H001** spool actuation type

**F001A** spool return action type

**RP G05** type and thread section

**01 PA 100** auxiliary valve (port A)


**05 PB** auxiliary valve (port B)

**3) OUTLET ARRANGEMENT: pag. 33** \_\_\_\_\_

**TJ** outlet type

**A G06** outlet position and available thread type

Ordering row 2 must be repeated for every work section




The connection ports size is indicated by an ordering code common for all Walvoil products. Following table shows all available connections; for ordering code refer to table on page 42.

Ports	BSP (ISO - 228)	Code	UN-UNF (ISO - 725)	Code
<b>Inlet Port (P)</b>	G 3/4	<b>G05</b>	1"1/16 - 12 UNF	<b>U05</b>
<b>Ports (A - B)</b>	G 3/4	<b>G05</b>	1"1/16 - 12 UNF	<b>U05</b>
<b>Outlet (T) - Carry over (HPCO)</b>	G 1	<b>G06</b>	1"5/16 - 12 UNF	<b>U06</b>
<b>Hydraulic Pilot</b>	G 1/4	<b>G02</b>	9/16" - 18 UNF	<b>U02</b>
<b>Pneumatic Pilot</b>	G 1/8	-	NPTF 1/8-27	-



## Tie-rod kit classification (appendix "A")

Tie rod kit allows the correct assembly of sectional valves. Tie rod's length depends on the number of sections; each valve is assembled with tie rod kits including a tie rod, two nuts and two washers. D16 requires 4 tie-rod kits.



Tie rod kit	Order Code	Length (mm)	Clamping Torque (Nm)	Quantity
D16/1	300145001	200	50	4
D16/2	300145002	246		
D16/3	300145003	292		
D16/4	300145004	338		
D16/5	300145005	384		
D16/6	300145006	430		
D16/7	300145007	476		
D16/8	300145008	522		
D16/9	300145009	568		
D16/10	300145010	614		
D16/11	300145011	660		
D16/12	300145012	706		

## Painting

On request, all Walvoil valves can be delivered painted (RAL 9005 black primer).

## Order example of D16/1 painted:

D16/1  
IR 009 150 A G05  
W001A H001 F001A RP G05 01 PA 100 05 PB  
TJ A G06  
**P006/1 N10**

The painting is indicated with the following value:

**P006 - /1 - N10**


Color black  
section number  
Painted



## D16 ■ SECTIONAL VALVE

walvoil  
MOTORS BY PEOPLE

### DIMENSIONS





TYPE	/1	/2	/3	/4	/5	/6	/7	/8	/9	/10	/11	/12
X (mm)	147	193	239	285	331	377	423	469	515	561	607	653
Y (mm)	170	216	262	308	354	400	446	492	538	584	630	676
Weights (kg)	19,1	24,1	29,2	34,4	39,5	44,5	49,6	54,7	59,8	64	70	75,1





TYPICAL CURVES

Indicated values have been tested with standard sectional valve and W001A spool.



**Pressure drop (P - T)**



**Pressure drop (P - A/B)**




**Pressure drop (A/B - T)**



**Pilot operated relief valve curve**

**Setting ranges**

type	pressure (bar)
A	0 - 40
B	41 - 180
C	181 - 250
D	251 - 350





**TYPICAL CURVES**




Indicated values have been tested with standard sectional valve and W001A spool.

**Antishock valve curve**

Setting ranges		
type	pressure (bar)	
	at full flow	at min. flow
A	70 - 150	70-A / 120-A
B	151 - 230	121-A / 200-A
C	231 - 280	201-A / 250-A
D	281 - 350	251-A / 350-A


**Combined valve curve**

Setting ranges		
type	pressure (bar)	
	at full flow	at min. flow
A	30 - 95	30-A / 65-A
B	96 - 150	66-A / 120-A
C	151 - 260	121-A / 230-A
D	261 - 350	231-A / 350-A



**Main anticavitation check valve curve**

**Anticavitation check valve curve**




## INLET SECTION


## Order example

		IR	009	150	A G05
1.	<b>IR</b>	inlet side classification			
1.	<b>009</b>	valve arrangement			
1.	<b>150</b>	setting (bar)			
2.	<b>A G05</b>	inlet position and available thread type			




Rif.	Code	Description	Page
-	<b>IR</b>	Sectional valve with right inlet section	
	<b>IL</b>	Sectional valve with left inlet section	<b>11</b>
1	<b>009</b>	Pilot operated pressure relief valve	
	<b>010</b>	Pilot operated pressure relief valve and Main anticavitation check valve	
	<b>012</b>	Pilot operated pressure relief valve and Solenoid dump valve 12 Vdc	
	<b>013</b>	Pilot operated pressure relief valve and Solenoid dump valve 24 Vdc	
	<b>019</b>	Without valves	
	<b>020</b>	Main anticavitation check valve	<b>12</b>
2	<b>A G05</b>	Upper inlet (thread G 3/4)	
	<b>C G05</b>	Central side inlet (thread G 3/4)	
	<b>A U05</b>	Upper inlet (thread 1"1/16-12 UNF)	
	<b>C U05</b>	Central side inlet (thread 1"1/16-12 UNF)	

**NOTE:** when ordering a relief valve it is necessary to specify factory setting (example 150).

**Inlet side classifications**

**Valve identification**

<b>type</b>	<b>schema</b>	<b>layout</b>	<b>description</b>	<b>type</b>	<b>schema</b>	<b>layout</b>	<b>description</b>
<b>2</b>			Pilot operated pressure relief valve	<b>6</b>			Externally piloted valve
<b>3</b>			Relief valve plugged	<b>7</b>			Solenoid dump valve 12 Vdc
<b>4</b>			Main anticavitation check valve	<b>8</b>			Solenoid dump valve 24 Vdc
<b>5</b>			2 stage pilot operated relief valve	<b>11</b>			Plug with pressure-gauge connection

**Valve arrangement**

**Combination valve example: 009 = 2A - 3B**
**009** Combination valve

**2A** Pressure relief valve in port A

**3B** Relief valve plugged in port B

**The code identifies:**

with a number, the type of valve; with a letter its position on the inlet section.

(A) = spool action side

(B) = spool return action side

**NOTE:** when ordering a main relief valve it is necessary to specify setting



VALVE COMBINATION INLET SECTION	Valve type on port B								
	2	3	4	5	6	7	8	11	
	2		<b>009</b>	<b>010</b>		<b>011</b>	<b>012</b>	<b>013</b>	<b>016</b>
	3	<b>018</b>	<b>019</b>	<b>020</b>	<b>021</b>	<b>022</b>	<b>023</b>	<b>024</b>	<b>027</b>
	4	<b>029</b>	<b>030</b>		<b>031</b>	<b>032</b>	<b>033</b>	<b>034</b>	<b>037</b>
	5		<b>038</b>						
	6	<b>047</b>	<b>048</b>						
	7	<b>054</b>	<b>055</b>						
	8	<b>061</b>	<b>062</b>						
	11	<b>085</b>							

**NOTE:** Valve combinations 021, and 038 requires double setting (see example).

Order example for inlet section: IR **038 200\*280 A G05**

**038  
200\*380**


valve combination  
double range setting (bar)

Inlet combination and thread available	
<b>A G05</b>	 Upper inlet (thread G 3/4)
<b>A U05</b>	 Upper inlet (thread 1"1/16-12 UNF)
<b>B G05</b>	 Upper inlet P1 with pressure-gauge connection G1/4 (thread G 3/4)
<b>B U05</b>	 Upper inlet P1 with pressure-gauge connection G1/4 (thread 1"1/16-12 UNF)
<b>C G05</b>	 Central side inlet (thread G 3/4)
<b>C U05</b>	 Central side inlet (thread 1"1/16-12 UNF)
<b>D G05</b>	 Central side inlet P1 with pressure-gauge connection G1/4 (thread G 3/4)
<b>D U05</b>	 Central side inlet P1 with pressure-gauge connection G1/4 (thread 1"1/16-12 UNF)

## WORKING SECTION

Order example:

	<b>W001A</b>	<b>H001</b>	<b>F001A</b>	<b>RP G05</b>	<b>01 PA 100</b>	<b>05 PB</b>
1.	<b>W001A</b>	spool type				
2.	<b>H001</b>	spool actuation type				
3.	<b>F001A</b>	spool return action type				
4.	<b>RP G05</b>	section and thread type				
5.	<b>01 PA 100</b>	auxiliaty valve (port A - handle side)				
6.	<b>05 PB</b>	auxiliaty valve (port B - cap side)				



Rif.	Code	Description	Page
1	<b>W001</b> <b>W002</b>	3 positions double-acting 3 positions double-acting A-B to tank	<b>14</b>
2	<b>H001</b> <b>H005</b>	Protected lever hydraulic actuation	<b>16</b>
3	<b>F001A</b> <b>F002A</b>	3 positions spring-centred spool (spring A) 3 positions spring-centred spool detent in A and B (spring A)	<b>17</b>
4	<b>RP G05</b> <b>RP U05</b> <b>RS G05</b> <b>RS U05</b>	Parallel circuit (G 3/4) Parallel circuit (1"1/16-12 UNF) Series circuit (G 3/4) Series circuit (1"1/16-12 UNF)	<b>25</b>
5	<b>01 PA 100</b> <b>05 PA</b>	Antishock valve (port A) Prearrangement for auxiliary valve (port A)	<b>26</b>
6	<b>01 PB 100</b> <b>05 PB</b>	Antishock valve (port B) Prearrangement for auxiliary valve (port B)	

**NOTE:** (\*) Leave out the spool return action code when choosing H005.

Sections designed to house auxiliary valve option require double choice on work ports A and B.










Always indicate setting value when using antishock and combined valve: **01 PA (100) - 03 PA (100)**



## Spool identification

order example of spool: **W001 A J10**

<b>W001</b>	spool schema	3 positions double-acting	
<b>A</b>	spool type	standard spool	
<b>J10</b>	restricted service ports	restriction on diameter (0,10 mm in A and B)	

<b>W001</b>	3 positions double-acting	
<b>W002</b>	3 positions double-acting A and B to tank	
<b>W003</b>	3 positions double-acting A to tank B blocked	
<b>W004</b>	3 positions double-acting A blocked B to tank	
<b>W005</b>	3 positions single - acting on A	
<b>W006</b>	3 positions single - acting on B	
<b>W009</b>	3 positions double-acting with anticavitation valves	
<b>W010</b>	3 positions double-acting switch port closed (A - B blocked)	
<b>W011</b>	3 positions double-acting switch port closed (A - B to tank)	
<b>W012</b>	4 positions double-acting with float in the 4 <sup>th</sup> position	
<b>W013</b>	3 positions double-acting regenerative	
<b>W015</b>	3 positions double-acting series	
<b>W016</b>	3 positions double-acting series A and B to tank	



## D16 ■ SECTIONAL VALVE

walvoil  
MOTORS BY PEOPLE

code	circuit	spools with restricted service ports		
		restriction on diameter (mm)	section (mm <sup>2</sup> )	hydraulic schema
J10	A-B IN T	0,10	3,13	
K10	A IN T	0,10	3,13	
Y10	B IN T	0,10	3,13	

CODE	spool type available	
	STANDARD A	METERED B
W001	W001A	W001B
W002	W002A	W002B
W003	W003A	W003B
W004	W004A	W004B
W005	W005A	W005B
W006	W006A	W006B
W009	W009A	W009B
W010	W010A	
W011	W011A	
W012	W012A	
W013	W013A	
W015	W015A	
W016	W016A	

### NOTE:

- W012, W013, spools need a special machining on the valve body.
- W015, W016, spools need RS type body.
- Float spool (W012) need special detent kit (F005).
- Regenerative spool (W013) need special return spring kits.
- Different spools are available on request.

Please contact our Sales department for more information.



## Spool actuation classification for manual control


code	description	dimensions	configuration
H001	Protected lever		
H002	Protected lever rotated 180°		
H004	Control without lever		

## Spool actuation classification for Hydraulic control

code	description	dimensions	configuration
H006 <small>leave out the spool return action code</small>	Hydraulic actuation with side ports and cast-iron end caps  BSP ports = G 1/4 UNF ports = 9/16-18 UNF		

## Hydraulic pilot control curve

The diagram shows the spool stroke as a function of the pressure operating.






### Spool return action classification - Springs load values

Spool return kits have three different spring types; following the codes depending on spring loads.

Spring type			
Code	A (standard spring)	B (soft spring)	C (heavy spring)
<b>Preloading</b>	137.3 N	98.1 N	196.2 N
<b>End of stroke</b>	176.6 N	137.3 N	255 N
Spool return action identification example			
<b>Code</b>	<b>F001A</b>	<b>F001B</b>	<b>F001C</b>



code	description	schema	dimensions	configuration
<b>F001A</b>				
<b>F001B</b>	3 positions spring-centred spool	W[B 0 A]-		
<b>F001C</b>				
<b>F002A</b>	3 positions spring-centred spool detent in A and B	BA 0 YHW[B 0 A]-		
<b>F003A</b>	3 positions spring-centred spool detent in A	A 0 YHW[B 0 A]-		
<b>F004A</b>	3 positions spring-centred spool detent in B	B 0 YHW[B 0 A]-		
<b>F005A</b>	4 positions spring-centred spool detent in 4 <sup>th</sup> position (only for W012 spool)	4 0 YHW[B 0 A 4]-	92	
<b>F009A</b>	2 positions in A spring-centred spool	W[0 A]-		
<b>F010A</b>	2 positions in B spring-centred spool	W[B 0]-		
<b>F011A</b>	2 positions detent in A spring-centred spool	A 0 YHW[0 A]-		
<b>F012A</b>	2 positions detent in B spring-centred spool	B 0 YHW[B 0]-		
<b>F013A</b>	3 positions spring-centred spool			
<b>F013B</b>	prearrangement			
<b>F013C</b>	dual command			




Pneumatic control classification

code	description	schema	dimensions	configuration
F020A	Pneumatic control ON - OFF			
F021A	Pneumatic control ON - OFF rotated 180°			
F022A	Proportional Pneumatic control			Proportional control with port BSP: G 1/8
F023A	Proportional Pneumatic control rotated 180°			
F135A	Pneumatic control ON - OFF			
F136A	Pneumatic control ON - OFF rotated 180°			
F126A	Proportional Pneumatic control			Proportional control with port NPTF: 1/8-27
F127A	Proportional Pneumatic control rotated 180°			

Proportional pneumatic control curve

The diagram shows the spool stroke as a function of the pneumatic pressure operating.














## D16 ■ SECTIONAL VALVE

walvoil  
MOVING BY PEOPLE

### Load limit classification

code	description	schema	dimensions	configuration
<b>F024A</b>	Load limit in A and B			
<b>F024C</b>				
<b>F025A</b>	Load limit in A and B			
<b>F025C</b>	rotated 180°			
<b>F026A</b>	Load limit in A			
<b>F027A</b>	Load limit in A			
<b>F027C</b>	rotated 180°			
<b>F028A</b>	Load limit in B			
<b>F029A</b>	Load limit in B			
<b>F029C</b>	rotated 180°			


**NOTE:** on request is available the load limit with dual control; for more informations please contact our Commercial Dept.



## Electrical load limit classification

Spool position sensor			
Power supply	Contacts capacity	Protection degree	temperature range
12 vdc	3 A	IP 65	da -25°C a +90°C
24 vdc	1,5 A		

## Operational diagram




**CONTROL in A e B** = connect PIN 1 - 4 and 2 - 3

**CONTROL in A** = connect PIN2 - 3

**CONTROL in B** = connect PIN 1 - 4

## Wiring diagram



controllo utilizzo A

neutro in = 0

controllo utilizzo B

In case of inductive loads it is advisable to connect the terminals of the workport (solenoid) to a 200 VDC - 3A diode.

code	description	dimensions	configuration
<b>F0360</b>	Electrical load limit (normally closed contacts)		
<b>F0370</b>	Electrical load limit rotated 180° (normally closed contacts)		
<b>F0450</b>	Electrical load limit (normally open contacts)		
<b>F0460</b>	Electrical load limit rotated 180° (normally open contacts)		


**NOTE:** a HIRSCHMANN female connector, type G4 W1F, is available on request (code 413000045, to be ordered separately).




### Electrohydraulic control specifications

Operating temperature range	-20°C / +80°C
Max inlet pressure	350 bar
Reduced pressure	16 bar
Back pressure on (T)	3 bar
Filtering degree	25 µ assoluti
Racommended pilot pipe size	Ø 6 mm - G 1/4

#### Electrohydraulic ON-OFF control with fixed pressure reducing valve



#### Electrohydraulic PROPORTIONAL control with fixed pressure reducing valve



Proportional control kit, mechanically retrooperated, allows the maximum precision of positioning, limiting the hysteresis. The control is operated with PWM control of the current. PWM frequency suggest: 60-80 Hz

#### regulation currents

Nominal voltage (V)	Resistance R <sub>20</sub> (Ohm)	Current min (A)	Current max (A)
12 vdc	3,7	0,9	1,7
24 vdc	15,5	0,45	0,85



#### Electrohydraulic control classification

code	description	dimensions	configuration
<b>F1600</b>	3 positions electrohydraulic control ON - OFF 12 Vdc		
<b>F1610</b>	3 positions electrohydraulic control ON - OFF 24 Vdc		
<b>F2600</b>	3 positions electrohydraulic control PROPORTIONAL 12 Vdc		
<b>F2610</b>	3 positions electrohydraulic control PROPORTIONAL 24 Vdc		

Electrohydraulic ON-OFF control is stackable with electrohydraulic PROPORTIONAL control (F2600 = F2610). Control kit already includes orifice to make spool displacement more gradual.



## Electrohydraulic control with fixed pressure reducing valve classification

code	description	configuration
<b>F1500</b>	Electrohydraulic control ON - OFF (fixed pressure reducing valve) P - T inlet side (12 vdc)	 Port BSP (P - T) = G 1/4 Port UNF (P - T) = 9/16"18 UNF
<b>F1510</b>	Electrohydraulic control ON - OFF (fixed pressure reducing valve) P - T inlet side (24 vdc)	
<b>F2500</b>	Electrohydraulic control PROPORTIONAL (fixed pressure reducing valve) P - T inlet side (12 vdc)	
<b>F2510</b>	Electrohydraulic control PROPORTIONAL (fixed pressure reducing valve) P - T inlet side (24 vdc)	 Port BSP (P - T) = G 1/4 Port UNF (P - T) = 9/16"18 UNF
<b>F1520</b>	Electrohydraulic control ON - OFF (fixed pressure reducing valve) P inlet - T outlet (12 vdc)	
<b>F1530</b>	Electrohydraulic control ON - OFF (fixed pressure reducing valve) P inlet - T outlet (24 vdc)	
<b>F2520</b>	Electrohydraulic control PROPORTIONAL (fixed pressure reducing valve) P inlet - T outlet (12 vdc)	
<b>F2530</b>	Electrohydraulic control PROPORTIONAL (fixed pressure reducing valve) P inlet - T outlet (24 vdc)	

## Control tie rod assembly

The length of the control tie rod, will change depending on the section numbers; in this way it will be easy to install in the right way the sections and avoid any misassembly. Each kit is composed by 2 tie rods, 2 plugs, 2 connection ports and spacers according to the section number.


**NOTE:** the control tie rod kit has always to be ordered separately.

Reducing valve, combined with electrohydraulic control kit has to be calculated as a normal working section.

**ORDER EXAMPLE:**

Complete valves with 3 sections F1600 requires a complete tie-rod kit /3.

Complete valves with 2 sections F1600 and 1 section with F1500 (reducing valve) requires a complete tie-rod kit /4.





**Order code fixed pressure reducing valve:**

**915000303** = reducing valve for BSP ports  
**915000312** = reducing valve for UNF ports



**Order code for control tie rod (BSP):**

**320103001** = control tie rod /1  
**320105001** = control tie rod /2  
**320105002** = control tie rod /3  
**320105003** = control tie rod /4  
**320105004** = control tie rod /5  
**320105005** = control tie rod /6  
**320105006** = control tie rod /7  
**320105007** = control tie rod /8  
**320105008** = control tie rod /9

**Order code for control tie rod (UNF):**

**320103026** = control tie rod /1  
**320105026** = control tie rod /2  
**320105027** = control tie rod /3  
**320105028** = control tie rod /4  
**320105029** = control tie rod /5  
**320105030** = control tie rod /6  
**320105031** = control tie rod /7  
**320105032** = control tie rod /8  
**320105033** = control tie rod /9

**Electropneumatic control classification**

code	description	dimensions	configuration
<b>F0620</b>	3 positions electropneumatic control ON-OFF (12 vdc) 7 W - 0,58 A	Minimum working pressure  5 bar	
<b>F0630</b>	3 positions electropneumatic control ON-OFF (24 vdc) 7 W - 0,29 A		

**Control tie rod assembly**

The lenght of the control tie rod, will change depending on the section numbers; in this way it will be easy to install in the right way the sections and avoid any misassembly. Each kit is composed by 1 tie rod and 2 plugs.

**NOTE:** the control tie rod kit has always to be ordered separately.

**Order code for control tie rod (BSP):**

**320105013** = control tie rod /1  
**320105014** = control tie rod /2  
**320105015** = control tie rod /3  
**320105016** = control tie rod /4  
**320105017** = control tie rod /5  
**320105018** = control tie rod /6  
**320105019** = control tie rod /7  
**320105020** = control tie rod /8


**Order code for control tie rod (UNF):**

**320105037** = control tie rod /1  
**320105038** = control tie rod /2  
**320105039** = control tie rod /3  
**320105040** = control tie rod /4  
**320105041** = control tie rod /5  
**320105042** = control tie rod /6  
**320105043** = control tie rod /7  
**320105044** = control tie rod /8




Compatibility table

SPOOL ACTION TYPE	SPOOL TYPE																		
	W001A	W001B	W002A	W002B	W003A	W003B	W004A	W004B	W005A	W005B	W006A	W006B	W009A	W009B	W010A	W011A	W012A	W013A	W015A
H001	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
H002	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
H004	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
H006	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
SPOOL RETURN ACTION TYPE	SPOOL TYPE																		
F001	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F002	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F003	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F004	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F005	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F009	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F010	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F011	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F012	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F013	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F020=F021	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F022=F023	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F135=F136	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F126=F127	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F024=F025	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F026=F027	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F028=F029	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F0360=F0370	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F0450=F0460	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F0620=F0630	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F1500=F1510	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F1520=F1530	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F2500=F2510	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F2520=F2530	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F1600=F1610	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
F2600=F2610	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

**Work section identification**

When the spool is operated it intercepts the by-pass gallery by diverting the flow of oil to service port A or B. If two or more spools are actuated at the same time, the oil will power the service port that has the lower load; by throttling the spools, the flow of oil can be divided between two or more service ports.



When the spool is operated it intercepts the switch gallery by diverting the flow of oil to service port A or B. The oil that flows back from the actuator is carried to the switch gallery thus making it available to the service ports downstream from the series section. The pressure drop downstream is added to the pressure drop of the section itself.



## Auxiliary valve identification

code	description	schema	configuration	setting range (bar)			
				type	at full flow	type	at min. flow
01 PA	Antishock valve (port A)			A	70 / 150	A	70-A / 120-A
				B	151 / 230	B	121-A / 200-A
				C	231 / 280	C	201-A / 250-A
				D	281 / 350	D	251-A / 350-A
02 PA	Anticavitation valve (port A)						
03 PA	Combined valve (port A)			A	30 / 95	A	30-A / 65-A
				B	96 / 150	B	66-A / 120-A
				C	151 / 260	C	121-A / 230-A
				D	261 / 350	C	231-A / 350-A
04 PA	Pilot combined valve (port A)			A	50 / 420	A	50-A / 420-A
05 PA	Prearrangement for auxiliary valve (port A)						

code	description	schema	configuration	setting range (bar)			
				type	at full flow	type	at min. flow
01 PB	Antishock valve (port B)			A	70 / 150	A	70-A / 120-A
				B	151 / 230	B	121-A / 200-A
				C	231 / 280	C	201-A / 250-A
				D	281 / 350	D	251-A / 350-A
02 PB	Anticavitation valve (port B)						
03 PB	Combined valve (port B)			A	30 / 95	A	30-A / 65-A
				B	96 / 150	B	66-A / 120-A
				C	151 / 260	C	121-A / 230-A
				D	261 / 350	C	231-A / 350-A
04 PB	Pilot combined valve (port B)			A	50 / 420	A	50-A / 420-A
05 PB	Prearrangement for auxiliary valve (port B)						

## Auxiliary valve - Setting range

Sections designed to house auxiliary valve option require double choice on work ports A and B.  
Always indicate setting value when using antishock valve:

**01 PA (120) = setting at full flow**


**01 PA (120-A) = setting at min. flow**



**INTERMEDIATE INLET SECTION**

**Order example**

		BE	009	150	A G05
	<b>BE</b>	inlet side			
1.	<b>009</b>	valve arrangement			
	<b>150</b>	setting (bar); when ordering a main relief valve it is necessary to specify setting			
2.	<b>A G05</b>	inlet position and available thread type			




Rif.	Code	Description	Page
-	<b>BE</b>	Intermediate inlet section	
	<b>BV*</b>	Intermediate inlet section with pressure relief valve	<b>28</b>
1	<b>009</b>	Pilot operated pressure relief valve	
	<b>010</b>	Pilot operated pressure relief valve and Main anticavitation check valve	
	<b>019</b>	Without valves	
	<b>020</b>	Main anticavitation check valve	<b>29</b>
2	<b>A G05</b>	Upper inlet (thread G 3/4)	
	<b>A U05</b>	Upper inlet (thread 1"1/16-12 UNF)	


**NOTE:** when ordering a relief valve it is necessary to specify factory setting (example 150).  
\* = omit the code for inlet positioning and thread



## Intermediate inlet section classifications



The intermediate inlet section is driven by two pumps (P + P1). The downstream elements can be set to a lower pressure than the upstream ones by adjusting the pressure relief valve of the intermediate section in question.




The intermediate inlet section and the elements are driven by a single pump (P). The downstream elements can be set to a lower pressure than the upstream ones by adjusting the pressure relief valve of the intermediate section in question.

## Valve identification on intermediate inlet section

type	schema	layout	description	type	schema	configurazione	descrizione
2			Pilot operated pressure relief valve	4			Externally piloted valve
3			Relief valve plugged	11			Plug with pressure-gauge connection

## Valve arrangement on intermediate inlet section



## Combination valve example: 009 = 2A - 3B

- 009 Combination valve
- 2A Pressure relief valve in port A
- 3B Relief valve plugged in port B

## The code identifies:

with a number, the type of valve; with a letter its position on the inlet section.

(A) = spool action side

(B) = spool return action side

**NOTE:** when ordering a main relief valve it is necessary to specify setting



VALVE COMBINATION INLET SECTION	Valve type on port B				
Valve type on port A	2	3	4	11	
	2		009	010	016
	3	018	019	020	027
	4	029	030		
	11	085	086		

#### Inlet position and available thread type

Inlet combination and thread available	
A G05	
A U05	Upper inlet (P1)

#### Complete configuration samples for D16/2 with intermediate inlet section (BE)


IR 009 150 A G05..... Right inlet section

W001A H001 F001A RP G05 ..... Working section

**BE 009 150 A G05 .....**Intermediate inlet section

W001A H001 F001A RP G05 ..... Working section

TJ A G06 ..... Outlet section



#### Complete configuration samples for D16/2 with intermediate inlet section (BV)


IR 009 150 A G05..... Right inlet section

W001A H001 F001A RP G05 ..... Working section

**BV 009 150 .....**Intermediate inlet section

W001A H001 F001A RP G05 ..... Working section

TJ A G06 ..... Outlet section






## INTERMEDIATE OUTLET SECTION

Order example

BF | A G06

1. **BF** inlet side \_\_\_\_\_  
**A G06** inlet position and available thread type \_\_\_\_\_





Rif.	Code	Type	Description	Page
-	<b>BF</b>		Intermediate outlet section with single tank return	
	<b>BG</b>		Intermediate outlet section with two tank returns	
1	<b>A G06</b>		Upper outlet (thread G 1)	
	<b>A U06</b>		Upper outlet (thread 1"5/16-12 UNF)	
	<b>G G06</b>	for	Front outlet side A (thread G 1)	
	<b>G U06</b>	BF	Front outlet side A (thread 1"5/16-12 UNF)	31
	<b>H G06</b>		Rear outlet side B (thread G 1)	
	<b>H U06</b>		Rear outlet side B (thread 1"5/16-12 UNF)	
	<b>J G06</b>	for	Upper outlet HPCO - front side A and rear side B to T (thread G 1)	
	<b>J U06</b>	BG	Upper outlet HPCO-front side A and rear side B to T (thread 1"5/16-12 UNF)	



**Intermediate outlet section classifications**

**intermediate outlet type**



**BF**



Intermediate outlet section  
**with single tank return**

The above outlet section allows the flow of oil of the two pumps and the tank ports to be piped to a single outlet T.

**BG**




Intermediate outlet section  
**with two tank returns**

The section in question allows the flow of oil of the two pumps to be piped in two outlets: HPCO for powering another directional control valve, T for discharge of the work ports. In order to obtain this, the two T need to be linked.

**Outlet combination and thread available**


**A G06**



available  
only for  
**BF**

Upper  
outlet (T)


**A U06**



available  
only for  
**BF**

Front outlet  
side A (T)


**G G06**



available  
only for  
**BF**

Rear outlet  
side B (T)


**G U06**



available  
only for  
**BF**

Upper outlet (T)

**H G06**



available  
only for  
**BF**

Front outlet  
side A (T)

**H U06**



available  
only for  
**BF**

Rear outlet  
side A (T)

**J G06**



available  
only for  
**BF**

Upper outlet HPCO  
front side A and  
rear side B to T

**J U06**



available  
only for  
**BF**

Upper outlet HPCO  
front side A and  
rear side B to T

**Complete configuration samples for D16/2 with intermediate outlet section (BF)**


IR 009 150 A G05..... Right inlet section

W001A H001 F001A RP G05 ..... Working section

**BF A G06 .....Intermediate outlet section**

W001A H001 F001A RP G05 ..... Working section

IL 009 150 A G05..... Left inlet section

**Complete configuration samples for D16/2 with intermediate outlet section (BG)**


IR 009 150 A G05..... Right inlet section


W001A H001 F001A RP G05 ..... Working section

**BG J G06 .....Intermediate outlet section**

W001A H001 F001A RP G05 ..... Working section

IL 009 150 A G05..... Left inlet section




**OUTLET SECTION (VERSION 1 OUTLET)****Order example**

<b>TJ</b>	<b>A G06</b>
-----------	--------------

1. **TJ** outlet section type \_\_\_\_\_  
 2. **A G06** outlet position and available thread type \_\_\_\_\_

Rif.	Code	Description	Page
1	<b>TJ</b> <b>TK</b>	Outlet section with single return (T) right-side inlet (P) Outlet section with single return (T) left-side inlet (P)	
2	<b>A G06</b> <b>A U06</b> <b>C G06</b> <b>C U06</b>	Upper outlet (thread G 1) Upper outlet (thread 1"5/16-12 UNF) Central outlet (thread G 1) Central outlet (thread 1"5/16-12 UNF)	34

**OUTLET SECTION (HPCO VERSION OUTLET)****Order example - HPCO version Outlet**

<b>TM</b>	<b>M G06</b>
-----------	--------------

1. **TM** outlet section type \_\_\_\_\_  
 2. **M G06** outlet position and available thread type \_\_\_\_\_

Rif.	Code	Description	Page
1	<b>TM</b> <b>TN</b>	Outlet section with two return (T-HPCO) right-side inlet (P) Outlet section with two return (T-HPCO) left-side inlet (P)	
2	<b>M G06</b> <b>M U06</b> <b>N G06</b> <b>N U06</b>	HPCO upper outlet T (tank) rear outlet side B (thread G 1) HPCO upper outlet T (tank) rear outlet side B (thread 1"5/16-12 UNF) HPCO upper outlet T (tank) front outlet side A (thread G 1) HPCO upper outlet T (tank) front outlet side A (thread 1"5/16-12 UNF)	35





**Outlet with single tank classification**

**outlet identification**



**TJ**

Outlet section with single return (T)  
right-side inlet (P)




**TK**

Outlet section with single return (T)  
left-side inlet (P)



**outlet combination and thread available**

**A G06**




Upper outlet  
(thread G 1)

**A U06**

Upper outlet  
(thread 1"5/16 - 12 UNF)

**C G06**




Central outlet  
(thread G 1)

**C U06**

Central outlet  
(thread 1"5/16 - 12 UNF)

**G G06**

Front outlet side A  
(thread G 1)




only for  
**TK**

**G U06**

Front outlet side A  
(thread 1"5/16 - 12 UNF)

**H G06**

Rear outlet side B  
(thread G 1)




only for  
**TJ**




**H U06**

Rear outlet side B  
(thread 1"5/16 - 12 UNF)



**Outlet with two tanks classification**




outlet combination and thread available			
<b>M G06</b>		<b>only for TM</b>	HPCO Upper outlet T (TANK) rear outlet side B (thread G 1)
<b>M U06</b>			HPCO Upper outlet T (TANK) rear outlet side B (thread 1"5/16 - 12 UNF)
<b>N G06</b>		<b>only for TN</b>	HPCO Upper outlet T (TANK) front outlet side A (thread G 1)
<b>N U06</b>			HPCO Upper outlet T (TANK) front outlet side A (thread 1"5/16 - 12 UNF)
<b>P G06</b>		<b>only for TM</b>	HPCO Central outlet T (TANK) rear outlet side B (thread G 1)
<b>P U06</b>			HPCO Central outlet T (TANK) rear outlet side B (thread 1"5/16 - 12 UNF)
<b>Q G06</b>		<b>only for TN</b>	HPCO Central outlet T (TANK) front outlet side A (thread G 1)
<b>Q U06</b>			HPCO Central outlet T (TANK) front outlet side A (thread 1"5/16 - 12 UNF)




## CARRY-OVER CONNECTION (HPCO)

This option, available on all D16, allows the sectional valve to feed a second valve, by extending the free flow channel. In this configuration, the valve need a separated port for connection to tank.




It is possible to transform sectional valve from standard to HPCO version just by ordering the appropriate conic plug:



code (HPCO Plug identification)	description	q.ty
<b>413010207</b>	conic plug G 3/8 x 15	2



**D6 SPARE PARTS LIST**



Ref.	Description	Order code	Q.ty	Code	Note
1	Pilot operated pressure relief valve (*)	<b>6364</b>			Setting: 100 bar
		<b>2608</b>	1		Setting: 200 bar
		<b>2744</b>			Setting: 300 bar
2	Relief valve plugged	<b>430107001</b>	1		
	Main Anticavitation check valve	<b>915050701</b>	1	-	
	External piloted valve	<b>915040701</b>	1		
	Solenoid dump valve (12 vdc) (**)	<b>915040702</b>	1		
	Solenoid dump valve (24 vdc) (**)	<b>915040703</b>	1		
	Plug with pressure-gauge connection	<b>430107003</b>	1		
3	3 positions double-acting spool	<b>421245016</b>	1	<b>W001A</b>	
		<b>421245028</b>	1	<b>W001B</b>	
	3 positions double-acting A and B to tank spool	<b>421245002</b>	1	<b>W002A</b>	
		<b>421245015</b>	1	<b>W002B</b>	
	3 positions single-acting on A	<b>421245005</b>	1	<b>W005A</b>	
	3 positions single-acting on B	<b>421245021</b>	1	<b>W006A</b>	
4	4 positions double-acting with float in the 4 <sup>th</sup> pos.	<b>421245027</b>	1	<b>W012A</b>	
	Protected lever	<b>320306006</b>	1	<b>H001 = H002</b>	only for W012 spool
		<b>320306007</b>	1		
	Control without lever	<b>320306002</b>	1	<b>H004</b>	only for W012 spool
5	Hydraulic actuation with side ports	<b>320306004</b>	1		
		<b>320545001</b>	1	<b>H006</b>	



Ref.	Description	Order code	Q.ty	Code	Note
	3 position spring centred spool	<b>320706001</b>	1	<b>F001A</b>	
	Detent in A and B	<b>320806001</b>	1	<b>F002A</b>	
	Detent in A	<b>320806002</b>	1	<b>F003A</b>	
	Detent in B	<b>320806003</b>	1	<b>F004A</b>	
	Detent in 4 <sup>th</sup> position	<b>320806004</b>	1	<b>F005A</b>	only for W012 spool
	Prearrangement dual command	<b>320706002</b>	1	<b>F013A</b>	
	Pneumatic control ON-OFF	<b>321106002</b>	1	<b>F020A=F021A</b>	BSP ports
	Proportional Pneumatic control	<b>321206002</b>	1	<b>F022A=F023A</b>	BSP ports
	Electropneumatic control ON-OFF (12 vdc)	<b>321645001</b>	1	<b>F0620</b>	
	Electropneumatic control ON-OFF (24 vdc)	<b>321645002</b>	1	<b>F0630</b>	
	Load limit in A and B	<b>320045005</b>	1	<b>F024A=F025A</b>	BSP ports
	Load limit in A	<b>320045003</b>	1	<b>F026A=F027A</b>	BSP ports
	Load limit in B	<b>320045004</b>	1	<b>F028A=F029A</b>	BSP ports
<b>4</b>	Electrical load limit (normally closed contacts)	<b>320045001</b>	1	<b>F0360=F0370</b>	
	Electrical load limit (normally open contacts)	<b>320045013</b>	1	<b>F0450=F0460</b>	
	Electrohydraulic ON-OFF (12 vdc)	<b>321445001</b>	1	<b>F1600</b>	
	Electrohydraulic ON-OFF (24 vdc)	<b>321445002</b>	1	<b>F1610</b>	
	Electrohydraulic Proportional (12 vdc)	<b>322045001</b>	1	<b>F2600</b>	
	Electrohydraulic Proportional (24 vdc)	<b>322045002</b>	1	<b>F2610</b>	
	Electrohydraulic ON-OFF (12 vdc) with reducing valve	<b>321445003</b>	1	<b>F1500=F1520</b>	BSP ports
	Electrohydraulic ON-OFF (24 vdc) with reducing valve	<b>321445004</b>	1	<b>F1510=F1530</b>	BSP ports
	Electrohydraulic Proportional (12 vdc) with reducing valve	<b>322045003</b>	1	<b>F2500=F2520</b>	BSP ports
	Electrohydraulic Proportional (24 vdc) with reducing valve	<b>322045004</b>	1	<b>F2510=F2530</b>	BSP ports
	Electrohydraulic ON-OFF (12 vdc) with reducing valve	<b>321445005</b>	1	<b>F1500=F1520</b>	UNF ports
	Electrohydraulic ON-OFF (24 vdc) with reducing valve	<b>321445006</b>	1	<b>F1510=F1530</b>	UNF ports
	Electrohydraulic Proportional (12 vdc) with reducing valve	<b>322045006</b>	1	<b>F2500=F2520</b>	UNF ports
	Electrohydraulic Proportional (24 vdc) with reducing valve	<b>322045007</b>	1	<b>F2510=F2530</b>	UNF ports
<b>5</b>	Check valve on the work section	<b>320204008</b>	1	-	only for RP and RT section
		<b>4209</b>			Setting: 100 bar
	Antishock valve on port A	<b>2743</b>		<b>01 PA</b>	Setting: 200 bar
		<b>2948</b>	1		Setting: 300 bar
<b>6</b>	Anticavitation valve on port A	<b>915080601</b>		<b>02 PA</b>	
	Prearrangement for auxiliary valve on port A	<b>430406001</b>		<b>05 PA</b>	
		<b>4209</b>			Setting: 100 bar
	Antishock valve on port B	<b>2743</b>		<b>01 PB</b>	Setting: 200 bar
		<b>2948</b>	1		Setting: 300 bar
<b>7</b>	Anticavitation valve on port B	<b>915080601</b>		<b>02 PB</b>	
	Prearrangement for auxiliary valve on port B	<b>430406001</b>		<b>05 PB</b>	
	Plug kit (G 3/4)	<b>430000020</b>		<b>G05</b>	
<b>8</b>	Plug kit (G 1)	<b>430000021</b>	1	<b>G06</b>	
	Plug kit (1"1/12"-16 UNF)	<b>300007002</b>		<b>U05</b>	



## D16 ■ SECTIONAL VALVE

walvoil  
MOTORS BY PEOPLE


### Note


(\*) = for different settings please contact our Sales Dpt.

(\*\*) = electric dump valve coil can be ordered separately as spare part: (see drawing "A")  
Ordering code Coil 12 vdc: 413171235  
Ordering code Coil 24 vdc: 413172432

(#) = Detent in A and B Kick-out is available only with special spool assembly

Coil - 12 Vdc = 413171235  
Coil - 24 Vdc = 413172432





Outlet and work section			
Rif.	Order code	Description	Q.ty
1	412010609	O.R. 70SH 23,47 x 2,62 (2-119)	3
2	412010603	O.R. 70SH 39,34 x 2,62 (2-129)	1

Complete Gasket kit: order code - 350945001



## INSTALLATION AND MAINTENANCE

### Guidelines

- Mount the control valve securely to a flat surface (recommended 3 point fixing); at the time do not use a hammer to positioning by hitting.
- When handling the control valve, be careful not hold the pilot cover or return spring cap of the spool or accessory valves such as main relief valves and anti-shock relief valves.
- Clean piping materials sufficiently before use.
- Make sure to prevent the port openings from being entered with dust or foreign matters.
- Tighten the port connectors surely with the recommended fastening torques.
- Do not direct the jet of a pressure washing unit directly to the valve.

### Fittings tightening torque (Nm)

thread type	port P	Port A - B	Port T
<b>BSP (ISO - 228)</b>	<b>G 3/4</b>	<b>G 3/4</b>	<b>G 3/4</b>
with rubber sealing (DIN 3869)	120	120	120
with copper or steel and rubber washer	120	120	120
<b>BSP (ISO - 228)</b>	<b>G 1</b>	<b>G 1</b>	<b>G 1</b>
with rubber sealing (DIN 3869)	150	150	150
with copper or steel and rubber washer	150	150	150
<b>UN-UNF (ISO - 725)</b>	<b>1"1/16 12 UNF</b>	<b>1"1/16 12 UNF</b>	<b>1"1/16 12 UNF</b>
with O.R.	120	120	120
<b>UN-UNF (ISO - 725)</b>	<b>1"5/16 12 UNF</b>	<b>1"5/16 12 UNF</b>	<b>1"5/16 12 UNF</b>
with O.R.	120	120	120



## Dimensions - Thread codes


The connection ports size is indicated by an ordering code common for all Walvoil products. Following table shows all available connections.

METRIC THREAD (ISO 9974-1)		
Type	M18x1,5	M22x1,5
Code	<b>M01</b>	<b>M02</b>
	<b>M03</b>	

BSP THREAD (ISO 1179-1)								
Type	1/4"	3/8"	1/2"	3/4"	1"	1"1/4	1"1/2	2"
Code	<b>G02</b>	<b>G03</b>	<b>G04</b>	<b>G05</b>	<b>G06</b>	<b>G07</b>	<b>G08</b>	<b>G09</b>

UN / UNF THREAD (ISO 11926-1)						
Type	9/16" 18 UNF SAE6	3/4" 16 UNF SAE8	7/8" 14 UNF SAE10	1"1/16 12 UNF SAE12	1"5/16 12 UNF SAE16	1"5/8 12 UNF SAE20
Code	<b>U02</b>	<b>U03</b>	<b>U04</b>	<b>U05</b>	<b>U06</b>	<b>U07</b>

## Dimensions - SAE Flange codes



SAE / 3000 FLANGE (ISO 6162-1)												
Type	3/4" (MA)	3/4" (UNC)	1" (MA)	1" (UNC)	1"1/4 (MA)	1"1/4 (UNC)	1"1/2 (MA)	1"1/2 (UNC)	2" (MA)	2" (UNC)	3" (MA)	3" (UNC)
Code	<b>S03</b>	<b>S04</b>	<b>S05</b>	<b>S06</b>	<b>S07</b>	<b>S08</b>	<b>S09</b>	<b>S10</b>	<b>S11</b>	<b>S12</b>	<b>S15</b>	<b>S16</b>
A	19	19	25	25	32	32	38	38	51	51	76	76
B	47,6	47,6	52,4	52,4	58,7	58,7	69,9	69,9	77,8	77,8	106,4	106,4
C	22,3	22,3	26,2	26,2	30,2	30,2	35,7	35,7	42,9	42,9	61,9	61,9
D	M10	3/8-16	M10	3/8-16	M10	7/16-14	M12	1/2-13	M12	1/2-13	M16	5/8-11

SAE / 6000 FLANGE (ISO 6162-2)								
Type	3/4" (MA)	3/4" (UNC)	1" (MA)	1" (UNC)	1"1/4 (MA)	1"1/4 (UNC)	1"1/2 (MA)	1"1/2 (UNC)
Code	<b>S33</b>	<b>S34</b>	<b>S35</b>	<b>S36</b>	<b>S37</b>	<b>S38</b>	<b>S39</b>	<b>S40</b>
A	19	19	25	25	32	32	38	38
B	50,8	50,8	57,2	57,2	66,6	66,6	79,3	79,3
C	23,8	23,8	27,8	27,8	31,8	31,8	36,5	36,5
D	M10	3/8-16	M12	7/16-14	M14	1/2-13	M16	5/8-11



## GENERAL CONDITIONS AND PATENTS

### Introduction

These general conditions apply to all general supplies from Walvoil s.p.a., after receiving orders from the Customer. Should commercial terms such as EXW, DDP, etc be mentioned, of course the Incoterms of the International Chamber of Commerce must be referred to, according to the test existing when the general supply conditions are agreed on.

### Management of orders

No Customer's order is binding to Walvoil s.p.a. if Walvoil s.p.a. has not confirmed the order in writing. Walvoil s.p.a. commits to supplying the orders in compliance with the order confirmation that has been issued. Any disagreement with the content of the order confirmation must be communicated in writing to Walvoil s.p.a. within and no later than 5 days from the delivery of the order confirmation. The Customer commits to paying for the goods supplied by Walvoil s.p.a., according to the prices indicated on the order confirmation.

### Payment conditions

The Parties agree on the payment terms at the beginning of the supply. The terms will be indicated on the order confirmation. Should the Customer be late with the payments, Walvoil S.p.a. will be entitled to require the payment of interests on arrears based on the exiting Prime Rate increased by 2%. Should there be any payment delay, Walvoil s.p.a. will be entitled not to process the Customer's purchase order, even if it has already been confirmed.

### Delivery and shipment

The goods are always supplied Ex Works, even when Walvoil s.p.a. agrees with the Customer that the shipment, or a part of it, will be arranged by Walvoil s.p.a. It is agreed that the Customer will bear the risk of goods deterioration or damaging from the moment the goods are handed by Walvoil s.p.a. to the first carrier.

### Product characteristics

Walvoil s.p.a. commits to supplying good quality products, compliant with the technical specifications declared on the technical tables and on the catalogue. Walvoil s.p.a., even without notice, at its own discretion, reserves the right to modify the products as necessary, without these changes altering the main characteristics of the products.

### Claims

Any claims about defects on delivered products (just as an example: claims about the packaging, the number, the quantity or the external product characteristics) will have to be notified to Walvoil s.p.a. in writing, within and no later than 7 days from reception of the goods, otherwise the claims will be considered as null and void. Occult defects (the defects of the goods that cannot be spotted with a careful control of the goods received by the Customer), will have to be notified in writing to Walvoil s.p.a. within 7 days from the discovery of the defect, and anyhow no later than 12 months from the delivery of the goods, otherwise the claim will be considered as null and void. Even in case of claim or objection, the Customer will never be entitled to suspend or delay the payments to Walvoil s.p.a. for the products subject to claim or objection nor for any other supply.

**GENERAL CONDITIONS AND PATENTS****Warranty**

Should the products supplied by Walvoil not be compliant or have the required quality and should this defect be due to Walvoil, Walvoil s.p.a. commits, at its choice, to replace or repair the faulty products, as long as the defect or lack of compliance is notified to Walvoil s.p.a. in writing, as specified at point 6, within and no later than 18 months from product delivery. On the products that have been fixed or replaced in accordance with what specified above, the above-mentioned warranty applies. The 12 month duration starts from the date of repair or replacement. In case of defects, lack of quality or in case of lack of compliance for the supplied products, with the exception of fraud or serious offence, Walvoil s.p.a. only commits to repairing or replacing the faulty products, according to what specified above. This warranty replaces any other Supplier's warranty or liability established by the law. This warranty excludes any other liability contractual or extra-contractual by Walvoil s.p.a. on the products supplied by Walvoil (as a mere example: damage refund, loss of profit, product recall campaign, etc). Walvoil s.p.a. has signed a product civil liability police, with a suitable maximum coverage.

**Ownership retention**

The products supplied by Walvoil s.p.a. will be owned by the latter until Walvoil receives the complete payment for the supplied goods.

**Obligation confidentiality**

Walvoil s.p.a. commits to not disclosing the technical and commercial information it receives from the Customer, unless this information has already been publicly disclosed.

**Patents**

The Customer is not allowed to use the provided Products, or a part of them, their descriptions or drawings protected or not protected by Patent or registered trademark in order to design or make similar products, unless Walvoil s.p.a. previously issues its written authorization. Should Walvoil s.p.a. give its written authorization, all patents, trademarks, registered designs, copyrights and intellectual property rights related or connected to the Products provided by Walvoil s.p.a. will stay Walvoil's property. The Customer commits to respecting the highest confidentiality.

**Applicable law and court of jurisdiction**

Walvoil s.p.a.'s supplies are regulated by these General Supply Conditions and, for anything not defined here, by the Italian law. Any controversy related, generated or connected to the supply of Products by Walvoil s.p.a., where Walvoil s.p.a. is involved, will be exclusively dealt with by the Court of Bologna.



Walvoil worldwide

**WALVOIL S.P.A.**

DIREZIONE E COORDINAMENTO INTERPUMP GROUP S.P.A.  
Headquarters, Subsidiaries and Representative Offices

**Walvoil S.p.A. Headquarters**

Via Adige, 13/D . 42124 Reggio Emilia . Italy  
TEL. +39 0522 932411  
[info@walvoil.com](mailto:info@walvoil.com) | [www.walvoil.com](http://www.walvoil.com)

AUSTRALASIA

**Walvoil Fluid Power Australasia Pty Ltd**  
13 Vanessa Way . Delahey VIC 3037 . Melbourne . Australia  
TEL. +61 458 918 750  
[australasia@walvoil.com](mailto:australasia@walvoil.com)

BRAZIL

**Interpump Hydraulics Brasil Ltda | Walvoil Division**  
Rua Gilberto de Zorzi, 525 . Bairro Forqueta 95115-730  
Caxias do Sul (RS)  
TEL. +55 54 3289 7000  
[infobrasil@walvoil.com](mailto:infobrasil@walvoil.com)

CANADA

**Walvoil Canada Inc.**  
3100, Rue Jacob Jordan . Terrebonne . Qc J6X 4J6 . Canada  
TEL. +1 450 477 1076 Ext:225  
[info@walvoilcanada.com](mailto:info@walvoilcanada.com) | [www.walvoilcanada.com](http://www.walvoilcanada.com)

CHINA

**Walvoil Fluid Power (Dongguan) Co. Ltd**  
1st Floor, the Third Factory Area, Sijia, Shijie Town, Dongguan City  
Guangdong province, China.  
TEL. +86 769 81816189-8020  
[info@walvoil.com.cn](mailto:info@walvoil.com.cn) | [www.walvoil.com.cn](http://www.walvoil.com.cn)

SOUTH KOREA

**Walvoil Fluid Power Korea Ltd.**  
(17818)80-15, Oseongsandan 1Ro, Oseong-myun, Pyeongtaek-si Gyeonggi-do  
Republic of Korea 451-872  
TEL. +82 31 682 6030  
[info@walvoil.co.kr](mailto:info@walvoil.co.kr) | [www.walvoil.co.kr](http://www.walvoil.co.kr)

FRANCE

**Walvoil Fluid Power France**  
362 rue de Bretagne . Vritz . 44540 Vallons-de-l'Erdre  
TEL. +33 2 41 94 41 06  
[france@walvoil.com](mailto:france@walvoil.com)

INDIA

**Walvoil Fluid Power (India) PVT. LTD.**  
No. 1, 2nd Cross, 2nd Main, KIADB Industrial Area, Attibele, Anekal Taluk  
Bangalore - 562107 .  
TEL. +91 80 0614 24000  
[info@walvoil.co.in](mailto:info@walvoil.co.in) | [www.walvoil.co.in](http://www.walvoil.co.in)

U.S.A.

**Walvoil Fluid Power Corp.**  
4111 North Garnett Tulsa, OK 74116, USA  
TEL. +1 918 858 7100  
[info@walvoilusa.com](mailto:info@walvoilusa.com) | [www.walvoilusa.com](http://www.walvoilusa.com)

**Walvoil Fluid Power Corp | Hydrocontrol Business Unit**

1109, Technology Drive . Red Wing . MN 55066 . U.S.A.  
TEL. +1 651 212 6400  
[info@walvoilusa.com](mailto:info@walvoilusa.com) | [www.walvoilusa.com](http://www.walvoilusa.com)

*3<sup>rd</sup> edition Jan.2024*

[www.walvoil.com](http://www.walvoil.com)



D1WHEB06E

